


Product Demo - Model No 8503




- Access and Attendance Reader
- Smart card OR Fingerprint
- DUAL Mode – Smartcard + fingerprint
- GPRS Enabled
- TCP/IP Enabled
- Attendance – Suitable at Office Entrances / Factory Gates
- Access- Suitable for Server Rooms, BPO, Call Centre, Sensitive areas



Product Demo - Model No 8503



- Model 8503 is suited for Attendance and access purpose.
- Follow the steps to understand method of working of this SAVIOR reader.




Product Demo - Model No 8503

Step 1

*(Smart Card+
Finger)*

- Use of Smart card by Staff / Employees
- Show the smart card on the front side of the SAVIOR Reader




Product Demo - Model No 8503



Step 2

- Put the enrolled finger on sensor area.
- SAVIOR Readers are able to recognize Smart card and Finger Print DUAL Mode (Useful for sensitive areas / offices and control proxy punching)




Product Demo - Model No 8503



Step 3

- Name and Paycode will be displayed on SAVIOR Reader in case of Valid Punch.
- The User card no, Date / Time will be recorded in SAVIOR Reader
- Electro Magnetic lock is installed on doors to allow / disallow access will operate. (if used for Access)



Product Demo - Model No 8503




Before



After lock is open

Copyright 2011 – STJ Electronics P Ltd




Product Demo - Model No 8503



Step 4

- In case user is invalid Message is displayed
- Invalid attempt is recorded




Product Demo - Model No 8503



(Only Finger)

Step 1

- Put the enrolled finger on sensor area. Reader sensor will glow.
- Reader will Identified Finger of User(Useful for sensitive areas / offices and control proxy punching




Product Demo - Model No 8503



Step 2

- If user is valid Name is displayed
- The User card no, Date / Time is saved in the reader




Product Demo - Model No 8503




Step 3

- In case user is invalid Message is displayed



Product Demo - Model No 8503

- Transfer of Data can be done at any time instance from SAVIOR Reader using appropriate communication channel.



- The data on PC is used by Software for reports and analysis for Access and Attendance.

